anex.


MAINTENANCE MANUAL INSTRUKCJA OBSŁUGI PŘÍRUČKA ÚDRŽBY BEDIENUNGSANI FITUNG MANUAL DE MANTENIMIENTO KASUTUSJUHEND MANUEL D'ENTRETIEN MANUAL F DI MANUTENZIONE სერვისის ინსტრუქცია PRIEŽIŪROS INSTRUKCIJA LIFTOŠANAS INSTRUKCIJA **ONDERHOUDSHANDLEIDING** MANUAL DE MANUTENÇÃO INSTRUCTIUNI DE ÎNTREȚINERE ИНСТРУКЦИЯ ОБСЛУЖИВАНИЯ UNDERHÅLLSMANUAL PRÍRUČKA ÚDRŽBY KULI ANIM KILAVUZU ІНСТРУКЦІЯ ОБСЛУГОВУВАННЯ РЪКОВОДСТВО ЗА ПОДДРЪЖКА

m/type PRO


| Unfolding the stroller | 5 |
|--|----|
| Folding the stroller | 6 |
| Handle regulation | 7 |
| Connection and disconnection of the axel and wheel | 7 |
| Assembly and disassembly of the front wheels | 9 |
| Locking front swivel wheels | 9 |
| Brake | 10 |
| Shock absorption | 10 |
| Basket removing | 11 |
| Assembling and disassembling of the carrycot | 11 |
| Hood adjustment | 12 |
| Hood ventilation | 13 |
| Carrycot ventilation | 14 |
| Carrycot footcover | 14 |
| Removing carrycot inside (cleaning) | 15 |
| Removing hood soft goods | 15 |
| Connection and disconnection of the seat | 16 |
| Seat hood adjustment/ventilation | 17 |

| Seat backrest adjustment | 18 |
|--|----|
| Footrest adjustment | 19 |
| Stroller's security barrier | 20 |
| Safety belts | 21 |
| Safety belts length adjustment | 22 |
| Safety belts height adjustment | 22 |
| Seat footcover | 23 |
| Removing seat hood | 24 |
| Removing seat soft goods | 25 |
| Connection and disconnection of the car seat adapter | 27 |
| Connection and disconnection of the car seat | 28 |
| Mosquito net | 28 |
| Rain cover | 29 |
| Backpack | 29 |


Unfolding the stroller



Folding the stroller




Handle regulation




Connection and disconnection of the axel and wheel









Assembly and disassembly of the front wheels




Locking front swivel wheels




Brake




Shock absorption




Basket removing





Assembling and disassembling of the carrycot






Hood adjustment






Hood ventilation




Carrycot ventilation




Carrycot footcover




Removing carrycot inside (cleaning)



Removing hood soft goods










Connection and disconnection of the seat







Seat hood adjustment/ventilation







Seat backrest adjustment







Footrest adjustment







Stroller's security barrier









Safety belts








Safety belts length adjustment




Safety belts height adjustment












Seat footcover










Removing seat hood









Removing seat soft goods












Connection and disconnection of the car seat adapter





Connection and disconnection of the car seat




Mosquito net





Rain cover



Backpack



Check for the most recent manuals our website: anexbaby.com

The information is subject to change without notice. Anex shall not be liable for technical errors or omissions contained in this manual. The purchased product may differ from the product as described in this manual.

Ideo Group LLC Al. Solidarnosci 117 00-140 Warsaw, Poland +48 22 211 67 08 office@anexbaby.com